



TRU-TURF

R52-11T GOLF ROLLER MANUAL

Contents

- 1. Important**
- 2. Machine Information Record**
- 3. Safety Information**
- 4. Warranty**
- 5. Assembly**
 - List of components
6.
 - Mounting seat to seat base
 - Mounting steering joystick to the steering shaft
 - Attaching trailer arm to machine
 - Attaching dampener strut and trailer arm
 - Attaching draw bar to trailer arm
 - Attaching wheels to trailer arm
7.
 - Correct dampener strut operation
 - Replacing oil
 - Transmission oil tank breather
 - Lubricating smoothing head pivot bearings
- 8. Operation**
 - Pre-operation checks
 - Standard operation Procedures
9.
 - Emergency and Park Brake
 - Points to remember
- 10. Maintenance**
 - Transmission (pump, Eaton 11)
 - Storing
 - Service of drive chain system
 - Lubrication
 - Service of smoothing roller bearings
11.
 - Change engine oil
 - Change transmission oil
 - Maintenance Schedule
- 12. Fault Finding**
 - Roller will not move one or either way
 - Roller will not steer
 - Roller has excessive vibration
 - Smoothing rollers seized
 - Rubber drive roller will not rotate
- 13. Machine Components**
- 36. Labels**
- 37. Options**
- 39. Parts List**

Separate Engine Owners Manual Included



Important

Please read and understand before operating machine.

1. Pre-check all nuts, bolts, grub screws for tightness prior to operating machine.
2. Understand the operating procedures and the controls before operating.
3. Use the machine to roll **18-36 greens** then **check** that all nuts, bolts etc. are tight. If loose and the Loctite seal has been broken, treat item as per Loctite instructions, reseal, then tighten securely.
4. **Loose transmission and drive roller sprockets will cause damage to shafts and keyways. Ensure they are correctly tightened at all times.**
5. **Change the transmission oil after 50 hours of operation, then as per the servicing schedule.**

We use and recommend Penrite Synthetic 5 SAE 5W-60. Available through our dealer network.

U.S.A. customers contact your dealer or visit www.truturf.com to find your nearest dealer.

Australian customers call 07 5594 7199.

International customers contact your dealer or visit www.truturf.com to find your nearest dealer.

Machine Information Record

Congratulations on your investment in the R52-11T Golf Green Roller and your move to smoother, faster, more consistent putting Greens. The following operation and maintenance manual has been prepared for use with the R52-11T Golf Green Roller. It is intended as a guide and supplemental updates to the manual may take place at a future date, without prior notice.

This machine is engineered to be simple to operate and easy to maintain. If you have any questions or concerns that this manual does not address, please feel free to contact your distributor.

Distributor Information

Name: _____

Address: _____

Telephone: _____

Fax: _____

Email: _____

Machine Information

Model. R52-11T Golf Green Roller

Serial No. _____

Engine No. _____

Transmission No. _____

Purchase Date No. _____

Safety Information

Safety Information

Safety is of the utmost importance when operating turf equipment.

To ensure safe operation of the R52-11T Golf Greens Roller, please follow the following safety guidelines.

- Always make a pre-operation inspection before you start the engine. If this procedure is not carried out damage to property or personnel may occur.
- Keep children, pets and inexperienced personnel away from the machine. This machine should only be operated by trained and skilled personnel - check with your supervisor if you are unsure.
- Know how to stop the engine when in motion. Read and understand engine manufacturers manual, as supplied.
- Never permit inexperienced operators to use the machine. This machine requires certain knowledge and expertise to operate it; you must be a trained person to use this machine. Unskilled persons can harm themselves and others if they operate this machine.
- Do not use in enclosed areas unless well ventilated. Carbon monoxide gases are dangerous if inhaled, it can cause death; use the machine outdoors.
- When transporting the roller, make sure the trailer lock down mechanism is secure to prevent premature release of the catch. If the trailer catch is not correctly engaged while towing and releases accidentally, the front of the roller can drop and dig into the ground, causing the machine to move dangerously in any direction causing bodily injury. When carrying out maintenance ensure the catch is engaged correctly; if it is not the trailer arm could fly up making contact with a person(s) causing serious injury.

- When engine is running, always keep hands and loose clothing away from rotating shafts, chains and sprockets in the transmission area. If hair, clothing or loose objects become entangled on a rotating shaft serious bodily injury could occur. Stop engine before opening safety cover fitted to the transmission area.
- Never ride on the machine when machine is being towed.

Operator, remember it is your responsibility to be aware of your surroundings. To avoid accidents, think safe and operate safe.

Warranty

One Year Warranty

Universal Conditions

Tru-Turf Equipment will either repair or replace any item or part of a Tru-Turf Equipment turf maintenance product that is defective in workmanship or material for a period of twelve (12) months from the date of delivery of the new product to the original end user. These items will be repaired or replaced free of charge and freight free.

Products Protected By This Warranty

This Warranty relates to the following products manufactured by Tru-Turf Equipment and parts used to make these products:- GR39 Golf Greens Roller; GR48 Golf Greens Roller; GR7000 Series Golf Greens Roller; GR11000 Series Golf Greens Roller; RS48 Roll 'n' Spike Golf Greens Roller; RS48-11 Series, Roll 'n' Spike Golf Greens Roller; R52-11T Tri Golf Greens Roller; R52-ELT Electric Golf Greens Roller; Triplex Roll 'n' Spike Mower Attachment Heads and Brackets; MT2000-S & D Single and Dual; MT5000-S&D Single and Dual Tote for Walk Behind Mowers; SR72 Sports Ground Roll 'n' Spike Turf Roller.

Parts Warranted By Suppliers To Tru-Turf

Specific component parts supplied to Tru-Turf Equipment are covered by that supplier's Warranty. These parts include Eaton Transmission, Honda Engines and Kohler Engines.

Normal Wear and Tear

Tru-Turf Equipment will not repair or replace parts subject to normal maintenance routines as specified in the products Operator's Manual nor to parts subject to wear and tear during the correct operation of the product. These parts include, but are not limited to, oils, filters, tires, shafts, bearings, blades, spikers, slicers, brakes, belts, hoses and spark plugs.

Other Items Not Covered By This Warranty

Tru-Turf Equipment will not repair or replace free-of-charge any item that has been damaged by accident, lack of reasonable care and protection or lack of suitable

storage. We will not cover parts that have been altered or modified by anyone other than Tru-Turf Equipment nor will we cover used parts that are installed in place of failed parts. We will not cover parts that have not been installed correctly by the end user or its agents nor will we cover parts that have not been maintained as per the Operator's Manual. Service calls and overtime labour rates will not be covered. We will not cover freight costs related to the return of the faulty product to Tru-Turf Equipment or its agents. Tru-Turf Equipment will not be liable for any consequential loss or damage or costs caused by or incidental to the failure of any new part supplied with the original purchase or any new part supplied as a replacement for any failed part.

Lodging Warranty Claims

The final purchaser of the new Tru-Turf Equipment product must lodge a Warranty Claim with Tru-Turf Equipment or its agents. The final purchaser must provide written evidence detailing the product's delivery date to that purchaser and the reasons why the purchaser believes that the product or its part is defective in the categories of faulty material or workmanship. The purchaser is to deliver the faulty product or part to Tru-Turf Equipment or its agents at the purchaser's expense. Acceptance or rejection of the Warranty Claim is entirely at the discretion of Tru-Turf Equipment or their Suppliers who warrant their own part/s.

No person or organization has the authority to modify the terms, conditions or limitations of this Warranty without the written consent of Tru-Turf Equipment.

Assembly

Initial Assembly

When you receive the crate, the machine will be broken down into components ready for assembly. If you run into any problems during assembly, please feel free to call your local distributor or agent.

List of Components

QTY	Description
1	Operation, Maintenance and Parts Manual
1	Machine Frame/Body
1	Drivers Seat
2	Armrests
4	$\frac{5}{16}$ " x $\frac{3}{4}$ " UNC Bolts
2	Tires mounted on Wheel Rim
1	Steering Joystick
1	Dampener Strut (attached to main body end)
1	Left-side Trailer Arm
1	Right-side Trailer Arm
2	30mm External Circlips
1	Drawbar Coupling Assembly
2	$\frac{3}{8}$ " x $1\frac{1}{2}$ " UNF 2P Bolts
2	$\frac{3}{8}$ " UNF Nyloc Nuts

Assembly

Assembly Procedure

Step 1: Mounting the seat to the seat base.

- Use the four $\frac{5}{16}$ " x $\frac{3}{4}$ " UNC bolts to fasten the seat to the seat base.
- Remove armrest screws from the seat, position left and right side armrest, fasten and tighten.

Step 2: Mount the steering joystick to the steering shaft.

- Select the steering joystick.
- Slide the joystick into the slot on the top of the steering shaft, already installed in the steering column directly in front of the foot pedal controls, insert the $\frac{3}{8}$ " bolt into the bottom bolt hole, select a comfortable operating position, joystick forward for extra operating room or back for less, once determined insert the other $\frac{3}{8}$ " bolt into the upper hole and tighten both bolts securely.

Step 3: Attaching the left-hand trailer arm to machine body.

- Locate the trailer arm support axle 30mm in diameter ($1\frac{1}{4}$ ") which extends out on the left side of the machine, remove the circlip from the support axle. Oil machined portion. Slide the left hand side trailer arm, onto the axle, replace the circlip, ensuring the circlip is located in the groove correctly.

Step 4: Attaching dampener strut and right hand trailer arm.

- Locate the trailer arm support axle 30 mm in diameter ($1\frac{1}{4}$ ") which extends out on the right side of the

machine, remove the circlip from the axle. Hold the right side trailer arm in the vertical position and slide it part way onto the axle. Locate dampener strut, remove packing from the unattached end.

- Place strut onto locating pin and push completely on, insert washer and cotter pin in place to prevent strut from coming off the shaft.
- If necessary use a soft headed hammer and tap the trailer arm onto the axle until the circlip groove is revealed, fit the circlip, ensuring it is located in the groove correctly.

Step 5: Attaching draw bar to trailer arms.

- Locate the draw bar assembly.
- Gather the ends of the right and left trailer arms.
- Place the draw bar assembly between the trailer arms and align the holes.
- Place one $2\frac{3}{4}$ " x $\frac{3}{8}$ " bolt through each hole, fit $\frac{3}{8}$ " Nyloc nut to each bolt and tighten securely.
- Test to ensure the trailer catch is correctly locking the trailer arms in the down position and the catch locking pin fits correctly when transporting the roller, for safety.

Step 6: Attaching wheels to trailer arms.

- Locate the two wheels for the left and right side trailer arms.
- Check tires for the correct air pressure, approximately 18psi. Do not exceed this pressure. The tires act as the suspension, hence the low P.S.I.

Assembly

- Remove wheel nuts from both hubs, slide wheels onto hub with air valves facing outwards. Replace wheel nuts and tighten securely.
- Ensure the taper on the nuts, mate into the wheel tapers correctly.

Step 7: Correct dampener strut operation

- When the roller is in the trailing position Carefully hold the draw bar assembly, release the locking catch, gently with a firm grip begin to raise the draw bar, when it has travelled sufficiently the dampener strut will take over and prevent the trailer arms rapidly rotating on it's axle, allowing the roller to lower to the surface gently. This prevents the operator from being injured. When the roller is resting on the ground push the trailer arms back gently, (do not use excessive force) until the trailer arms will travel no further. The dampener strut is designed to hold the trailer arms back behind the operator with the wheels off the ground.

Step 8: Replace engine oil

- A tag is placed on the engine's On/Off switch indicating you must fill the machine with oil prior to operation. Low oil level will cause the engine to stop on steep hills, the engine cut off safety switch is designed this way to protect the engine from damage if low in oil.
- The oil in the engine upon delivery (if not pre-delivered) is to prevent the inside of the engine from corroding, replace it with the correct engine oil, as per the manufacturers specifications.

Step 9: Transmission oil tank breather.

- Unscrew the plastic plug from the top of the tank and replace it with the anti-splash breather supplied. Seal damage and oil leakage will occur if the breather is not installed. If this is not done damage to the seals in the transmission will occur.

Step 10: Lubricate smoothing head pivot bearings.

- There is a grease nipple or zirk located on the three (3) smoothing head centre ball joint swivels. Apply grease to lubricate fittings.
- Apply grease to the upper main bearing that supports and carries the three smoothing heads.

Operation procedures

Operation procedures

Pre-operation checks

- Check engine as per Honda manual.
- Ensure steering joystick has no looseness.
- Check that foot pedal depresses under normal foot pressure in both directions and returns to the neutral position. (Similar resistance to a motor vehicle clutch). If this action is not smooth, check the yoke and transmission struts for correct operation.
- Ensure that the draw bar locking catch mechanism is securely locked to the main draw bar and the safety pin is fitted when trailing the roller.
- Check and tighten grub screws fitted to the end bearing lock rings on the rubber coated drive roller bearings on each smoothing head and main support bearing.
- Grease lightly Bearings fitted to Drive Roller and Smoothing Head pivot bearings. Replace plastic caps if fitted.
- Grease rod ends, sparingly.
- Check tire pressure for proper operating pressure (18psi). Do not over inflate.
- Check for oil and fuel leaks - rectify before using machine.
- Lubricate the drive chain with a suitable chain lubricant.

Standard operation procedures

- Inspect and check that the roller is serviceable prior to departing from workshop.
- Use a suitable towing vehicle to move roller from green to green.
- Maximum recommended towing speed would be equal to a motorized golf buggy. Approximately 4mph/7kph. Towing at excess speed or across rough terrain may cause damage to the machine and trailer.
- When approaching the green do not tow the roller onto the green to set up, put the roller on the fringe of the green. Put trailer in the up position, start up the roller and drive it onto the green.
- Greens can be rolled in any direction; take care to ensure there are no crease lines produced on the surface.
- It is recommended that you place the smoothing head rollers on the high side of the green when rolling. This increases the weight on the rubber drive roller and gives better traction, it also reduces slipping or spinning of the drive roller on the green, depending also on the operators ability. Whilst becoming familiar with the roller, set the throttle at about $\frac{1}{2}$ - $\frac{3}{4}$ speed. Press the left or right foot pedal down gently but not suddenly. Be smooth with your action, hold in this position until nearing the edge of the green, then take your foot gently off the pedal, the roller will come to a stop. Rest your other foot on the opposite pedal and gently apply the pressure to the pedal. It then starts to move the roller in the opposite direction. Once again be gentle with the pedal, but not sudden. By using the left and right pedal in this manner, will ensure there is no damage to the green and less wear and tear on the equipment and operator.

Operation procedures

- The correct procedure for rolling the green is:
 - (a) Select the correct direction to roll the green, remember this roller can roll the greens in all directions.
 - (b) Start on one side of the green and work your way across the green in a zigzag fashion, slightly overlapping each lap you roll: this makes sure you miss no part of the green and all of the green is rolled. Avoid coming back across the green to roll missed areas if possible. You should be able to complete the rolling of 18 greens in the same time or quicker than by mowing using a triplex mower.
- When rolling of the green is completed, move the roller onto the fringe, stop the engine, lock the trailer into the trailing position, connect it to the towing vehicle then move off to the next green to be rolled. Do not put the trailer down into the towing position on the green; damage may occur to the green from the roller tires and body.
- Remember turn off the fuel cock whilst towing the roller.

Emergency and Park brake

- To engage, push parking lever forward until it will travel no further, the lever operates on a over cam principal, when it is fully engaged the lever will remain in this position with the brake applied. To dis-engage the park brake, pull the lever up and back. The lever will remain in the off position until re-applied. Do not operate the roller with the emergency brake engaged, damage to the drive roller rubber coating will occur.
- Ensure the park brake is released prior to operating the roller, if not irreparable damage to the rubber on the drive roller will occur.

Points to remember

- Make sure the roller is serviceable before rolling.
- Start rolling from the fringe of the green.
- Smooth operation on the foot pedals.
- Pick a point on the other side of the green to roll to.
- Do not look at the green close to the roller; it makes it difficult to steer the roller straight; look well ahead.
- Use 1/2 throttle until you are proficient at operating the roller.
- Once you choose your rolling line hold the joystick steady, correcting direction gently as required.
- Move the steering joystick a little at a time to change direction; excessive movement of the joystick makes it difficult to maintain a straight line.
- Roll in straight lines.
- Do not leave the engine running with the roller parked on the green; the engine vibration will cause roller depression marks on the green.
- Move off the green when rolling is complete before putting the trailer in the down position.
- When rolling steep greens and the engine stops, check engine oil level. The engine is fitted with a safety switch; when the engine oil level is low the engine will stop.

Maintenance

Maintenance

- Stop engine before performing any maintenance.
- Service the Honda engine according to the manufacturer's maintenance schedule.

Transmission (pump, Eaton 11)

- Initially, change the oil at 50 hours running time, then;
- Change oil every 500 hours or annually, whichever occurs first.
- Change hydraulic oil filter every 500 hours or annually, whichever occurs first.
- Only use the manufacturer's recommended replacement oil filter .
- When fitting the filter, follow the instructions supplied with the filter. This will ensure that the filter remains tight and that no leaks occur.
- Check all hard line oil pipes for rubbing, excessive vibration, leaks and tightness on a regular basis.
- Check transmission oil level on oil tank sight glass. Oil level should remain at a minimum of 25mm (1") and at a maximum of 40mm (1.5") from the top of the tank.
- Oil Capacity including filter is 6 liters or 5.3 U.S. quarts. For the ultimate performance we use and recommend the Penrite synthetic 5 SAE 5W-60 transmission oil. (Part No. R5226)

Storing

- It is important to store this roller in the towing position. This ensures the trailer strut is in the closed position, protecting the shaft from corrosion, then failure and also the weight is taken off the roller bearings.

Service of the drive chain system

- Replacement - Some chains look a like, but they are not, use only the chain and sprockets recommended as per the correct spare parts number. Wrong pitch drive chain fitted will cause excessive sprocket wear and possible drive failure.
- Tensioning the drive chain - No adjustment is required; the chain tension is automatically adjusted.

Lubrication

- Lubricate Drive Chain with Chain Oil, WD40 or equivalent (CRC; Penetrene etc.) each time prior to rolling of the Greens.

Service of smoothing roller bearings

- Whilst the Roller is suspended by the Trailer, check operational smoothness of the bearings fitted to each smoothing roller by rotating the rollers by hand. If bearing tightness, roughness or excessive looseness is detected, replace the faulty bearings.

Maintenance

- If bearings are faulty
 - (a) Remove the complete smoothing head from the machine, undo the four swivel mount bolts on upper body and steering rod, wheel the roller away until the total head is exposed to work on.
 - (b) Remove roller shaft bolts from end plates, remove rollers from the heads.
 - (c) Screw a bolt back into the shaft end, knock out one end bearing, then use the same shaft to knock out the other end bearing.
 - (d) Fit new bearings, replace rollers into the heads, lubricate shaft bolts with an anti seize compound before installing them. Tighten securely and ensure rollers rotate freely when fully tightened.
 - (e) Be sure the spacing washers are fitted to the shaft ends before installing the rollers into the heads, in the correct sequence smaller diameter washer first and the larger diameter washer last.
 - (f) Sometimes, if the rollers do not rotate freely when installed use a soft headed hammer to hit the securing bolts on each end of the head, this will seat all parts and allow the roller to rotate freely.
 - (g) If the rods are removed or lengths altered ensure they are correctly adjusted so that the three heads are parallel to each other when in the straight ahead position. Adjust if necessary.

Changing transmission oil

- See page 12 and 14.

Ongoing Maintenance, Lubricant and Replacement Schedule (below)

Note. Areas indicated with a * need to be changed when defective or as required. This may be before the recommended replacement schedule. Please replace all parts as necessary.

Description	Pre-Delivery	Pre-Operating	12 Monthly
Check Engine oil	✓	✓	
Check Transmission Oil Level	✓	✓	
Beware of contaminants entering the transmission	✓	✓	
Lubricate drive chain with WD40 or equivalent	✓	✓	
Check Tires Max 18 P.S.I.	✓	✓	
Check Gas	✓	✓	
Check Smoothing Roller Bearing	✓	✓	
Check Drive Roller Bearings	✓	✓	
Check for loose Nuts and Bolts	✓	✓	
Renew Engine Oil	as per manufacturers Handbook		
Renew Transmission Oil - See page 1 for correct oil	every 500hrs or...		✓
Renew Transmission Oil Filter	*		✓
Renew Smoothing Roller Bearings	*		✓
Renew Drive Roller Bearings	*		✓
Renew Chain Tensioner Sprocket Bearings	*		✓
Renew Drive Chain	*		✓
Replace Foot Pedal Struts	*		
Replace Trailer Strut	*		

Changing engine oil

- Change oil and service as per the manufacturers Servicing Schedule enclosed as a separate insert to this manual.

Fault Finding

Fault Finding

Roller will not move one or either way, check

- Chain is okay
- Sprockets are not worn or slipping on the shaft
- Foot control is operating - check all arms are secure
- For Sheared Sprocket Keys
- Rubber coupling broken

Roller will not steer, check

- Woodruff Key is in place and not sheared
- Rod ends are connected to smoothing roller head and the steering arm
- Rod ends are not broken or seized
- Centre swivel bearing on top centre of each smoothing roller head has not seized
- Connecting rod are in place and serviceable

Roller has excessive vibration, check

- Disconnect engine-to- transmission and isolate the drive chain to determine whether the problem is in the engine or in the transmissions
- If engine is at fault contact your nearest engine agent for rectification
- If the transmission is at fault, repair or replace as

necessary, or seek professional advice from a local Eaton Service Center

- Any out of alignment between engine and transmission.
- For damaged engine and transmission couplings

Smoothing rollers seized, check


- Bearings have not seized
- Replace if necessary

Rubber drive roller will not rotate, check

- Roller shaft end bearings have not seized
- Broken chain
- Slipping sprockets
- the Park Brake is not locked on
- Accumulated dry debris is not locking the smoothing rollers.

Operating Positions


Towing Position




Rolling Position



Upper Body




Engine




Seat & Frame




Emergency Brake




Transmission




Fan & Coupling




Yoke & Struts




Chain Tensioner & Chain




Oil Tank & Pipes




Oil Tank & Pipes




Oil Tank & Fittings




Joystick & Steering Components




Underbody




Drive Roller




Tri Smoothing Heads




Tri Head Frame




Smoothing Roller




Steering & Connecting Rods




Foot Pedal




Trailer Components



RH Trailer Arm



Wheel Hub & Bearings







← T7003



Options



Options



Parts List

Part No.	Description	Page
E7003	Trailer Axle L-H Assy	33
E7004	Trailer Axle R-H Assy	33, 34
E7005	Drawbar Assy	33
E7006	Bush Plain Bronze	34
E7007	Bush Flanged Bronze	34
E7008	Smoothing Head 'T' Frame	28, 29
E7009	Tri Head Bearing 'T' Support	28, 29
E7010	Washer Tri Head Bearing	29
E7011	Housing F206 4 Hole	28, 29
E7012	Smoothing Head Steering	28
E7013	Smoothing Head Rear	28
E7014	Smoothing Head Centre	28
E7015	Rod Threaded Stabiliser	31
E7016	Rod Stabiliser Unit	28, 31
E7017	Rod Connecting Head	28, 31
E7019	Rod End Female Studded	31
E7020	Rod End Female	25, 31
E7023	Rod Threaded Heads	31
E7024	Tube Tie Rod Heads	31
E7025	Tube Tie Rod Stabiliser	31
E7026	Tube Smoothing Roller	30
E7027	Shaft Smoothing Roller	30
E7028	Steering Head Spacer	30
E7029	Steering Arm	25
E7030	Catch Trailer	14
E7033	Cap End RHS Plastic	29, 33
R5009	Grip Joystick	25
R5010	Bearing 6304	25
R5012	Pad Foot Pedal	32
R5014	Grip	14, 17
R5016	Catch Rubber	14, 16
R5031	Rubber Coupling	19
R5033	Fan Transmission	19
R5039A	Bush Taper Lock	27
R5046	Rod Unit Transmission Yoke	20, 32
R5049	Spring	14, 25
R5050	Bearing 6000	17, 21
R5061	Strap Mudflap Screw On	26
R5066	Drive Roller	27
R5067	Housing F205 4 Hole	28, 30
R5068	Housing LFL5J 2 Hole	27
R5070	Bearing B5	27, 30

Part No.	Description	Page
R5071	Mud Flap	26
R5075	Bush 27 Dia x 32	26, 32
R5077	Housing LFL6J 2 Hole	27
R5078	Bearing B6	27, 29
R5085	Shim Engine	15
R5087	Key Woodruff	27
R5089	Key Woodruff $\frac{3}{16} \times \frac{3}{4}$	19
R5094	Spring Chain Tensioner Arm	21
R5095	Washer Capped	21
R5099	Bush Bronze Chain Tensioner Arms	21
R5108	Ball Fitting Small Flange	20
R5109	Clip Retainer Long	20
R5111	Clip Retainer Short	20
R5114	Cup End Short	20
R5118	Rod End	20, 32
R5129	Meter Hour Tach	16
R5131	Eaton 11 Transmission Brkt	18, 19, 21, 22, 23
R5132	Chain Tension Arm	21
R5133	Transmission Eaton 11	18, 19, 21, 22, 23
R5136	Sprocket Pinion Transmission	21
R5139	Transmission Coupling Eaton 11	19
R5140	Engine Coupling Honda 6.5hp	19
R5141	Sprocket Drive Roller	27
R5142	Cushion Rubber Engine Mount	15
R5143	Tank Transmission Oil	22, 23
R5144	Breather Oil Tank	22, 24
R5145	Plug Tank Drain	22, 24
R5147	Cartridge Filter	22, 23, 24
R5148	Sight Gauge	22, 24
R5152	Pipe Transmission Oil	22, 23
R5153	Pipe Transmission Oil	22, 23
R5154	Pipe Transmission Oil	22, 23
R5156	Key Woodruff $\frac{1}{8} \times \frac{5}{8}$	21, 25, 32
R5168	Spacer Pedal Strut Yoke	20
R5169	Cup End Long	20
R5170	Strut Adjuster	20
R5171	Yoke Assy	20
R5173	Strut Transmission	20
R5178	Pipe Transmission Oil	22, 23
R5179	Ball Fitting Large Flange	20
R5183	28 1.2 27 Circlip Internal	21
R5184	Rod Transmission Yoke	20, 32

Parts List

Part No.	Description	Page
R5188	Sprocket Chain Tensioner	21
R5197	Rubber Strip Oil Tank	24
R5203	Strut End	33
R5210	Strut Kit	33
R5227	Fitting 90 Deg Elbow	18, 22
R5228	Fitting Straight	22, 23, 24
R5229	Fitting 90 Deg Elbow	22, 23, 24
R5230	Fitting Straight	18
R5231	Fitting Straight	22, 23, 24
R5232	Fitting 90 Deg Elbow	23, 24
R5233	Fitting 90 Deg Elbow	18, 22, 23
R5234	Fitting 90 Deg Elbow	18, 24
R5239	Latch Part B	14, 16
R5250	Thrust Washer Teflon	20
R5251	Chain Tension Arm Kit	21
R6009	Joystick Shaft	25
R6011	Spring Brake	17
R6013	Buffer Stop Under Body/Seat	16, 26
R6017	Pin Drawbar Safety	14
R6023	Plate Emergency & Park Brake	14, 36
R6024	Plate Move Right	14, 36
R6025	Plate Move Left	14, 36
R6026	Hub Trailer	34, 35
R6027	Seal Inner Hub	35
R6028	Bearing Hub Inner	35
R6029	Bearing Hub Outer	35
R6030	Washer Hub	35
R6031	Nut Stub	34, 35
R6032	Pin Cotter Stub Axle	34, 35
R6033	Cap Hub	34, 35
R6034	Wheel Nut	33
R6035	Wheel Hub Complete	35
R6039	Wheel 4 Stud	33
R6040	Decal Rolling Sloping Greens	36
R6041	Decal Danger	36
R6054	Seat Frame	16
R6055	Seat Plate	16
R6057	Decal Tru-Turf	36
R6058	Decal Tire Pressure	36
R6059	Decal PGA	36
R8005	Foot Pedal Arm	32
R8012	Engine Honda 6.5 HP	15

Part No.	Description	Page
R8013	Housing Filter Transmission Oil Tank	23,24
R8014	Circlip Smoothing Head	30
R8015	Washer Smoothing Roller	30
R8016	Bearing 6205 Stainless Steel	30
R8024	Seat Pan Msc	16
R8025	Arm Rest RHS	16
R8026	Arm Rest LHS	16
R8034	M8 Spring Washer	15, 16, 20, 26
R8035	10-12 x 16 Tek Screw	14, 16
R8037	M8 x 12 Bolt	15
R8038	M10 x 40 Bolt	33
R8039	M12 Nut Nyloc	25, 28
R8040	M6 x 16 Bolt	24
R8043	M8 Nut	15, 16, 20, 26
R8045	1/4 x 1 Washer	21
R8048	3/8 x 3/4 Washer	16, 17, 21
R8049	3/8 x 1 1/4 Washer	27, 30
R8050	1/4 Spring Washer	21
R8051	5/16 Spring Washer	15, 16
R8052	3/8 Spring Washer	27, 28, 29, 30
R8053	1/4 UNF Nut Nyloc	17
R8054	5/16 UNF Nut Nyloc	24
R8055	3/8 UNF Nut Nyloc P Type	16, 17, 20, 21, 25, 27, 28, 32, 33
R8056	3/8 UNF Nut Nyloc T Type	14, 17
R8057	7/16 UNF Nut Nyloc	27, 29
R8058	5/16 UNF Nut	19
R8059	1/4 x 1 UNC Bolt	21
R8060	1/2 UNC Nut Nyloc	20, 25, 32
R8062	1/4 x 2 1/4 UNF Bolt	17
R8064	5/16 x 1 UNF Bolt	24
R8065	5/16 x 1 1/2 UNF Bolt	15, 19
R8066	3/8 x 3/4 UNF Bolt	27, 29
R8067	3/8 x 1 UNF Bolt	16, 30
R8068	5/16 x 3/4 UNC Bolt	16
R8069	3/8 x 1 1/4 UNF Bolt	17, 20, 27, 28, 29, 32
R8070	3/8 x 1 1/2 UNF Bolt	25
R8072	3/8 x 2 1/2 UNF Bolt	14, 17, 33
R8073	3/8 x 3 UNF Bolt	21
R8074	7/16 x 1 1/4 UNF Bolt	27, 29
R8075	M4 x 40 Cotter Pin	14, 16
R8076	6-3 Rivet	14
R8077	5-4 Rivet	14, 16

Parts List

Part No.	Description	Page
R8078	4-4 Rivet Black	14
R8079	5/16 x 5/16 UNF Grub Screw	19, 21
R8080	202 x 4.7mm Zip Tie	16
R8081	10-24 x 16 Tek Screw	19, 26
R8082	27.6 29 29 Circlip External	14
R8084	5/16 x 2 1/2 UNF Bolt	24
R8085	M6 Spring Washer	24
R8086	M12 Nut Thin	31
R8087	M12 Nut Std	28, 31
R8088	M10 Nut	33
R8089	M12 Spring Washer	28
R8090	1/4 x 1/4 UNC Grub Screw	27, 29, 30
R8092	M12 x 45 Bolt	28
R8093	M12 x 75 Bolt	25
R8152	Washer Flat	30
T7000	Body Complete	14, 26
T7001	Transmission Cover	14
T7002	Plate Checker	14
T7003	Plate Serial Number	14, 36
T7004	Engine Mount Plate	15
T7005	Hand Brake	17
T7006	Brake Plate Assy	17, 26
T7007	Shaft Foot Pedal	32
T7008	Foot Pedal Selector	32
T7009	Chain Duplex Eaton 11	21
T7010	Joystick	25
T7011	Rod Steering Unit	25, 28, 31
T7012	Rod Threaded Steering	31
T7013	Tube Tie Rod Steering	31

Options

E7034	Drive Roller Countour Following	38
E7035	Scraper Rods (9 Total)	38
E7036	Polyurethane Smoothing Rollers	38
R5119	Light 55W	37
R5123	Switch	37
R5125	Light Post	37
R5126	Light Switch Bracket	37
R8094	1/4 UNF Nut Nyloc Stainless Steel	38
R9008	Light Kit	37

