

## GR48 TRU-TURF EQUIPMENT NOV '04

Number	SPARE PARTS LIST	Use
R39139-A	30Tooth Simplex Sprocket	R5039
R39158-A	11 Tooth Simplex Sprocket (Eaton Trans. Only)	R5035
R39159-A	Key Woodruff (Eaton Transmission only)	R5090
R39185	Engine Honda	R5029
R39206	Transmission Mount (Eaton Transmission)	R5043
R39208	Coupling; Eaton 7 Transmission - Honda 4 HP Engine	R5032
R39209	Centring Plate Adjustor (Eaton Transmission)	R5116
R39210	Centring Arm (Eaton Transmission)	R5048
R39211	Transmission Control Arm (Eaton Trans)	R5045
R39213	Chain Adjustor LH	R5038
R39214	Chain Adjustor RH	R5038
R39215	Nylon Bush Chain Adjustor. Not Avail. Supply R5038Kit	R5038 kit
R39216	Bearing; 6000	R5050
R39217	Sprocket 12 tooth Simplex	R5037
R5000	Body; Main; RS48, RS48-11& GR48	
R5002	Frame; Seat Mount	
R5003	Plate; Seat Base	
R5004	Pin; Seat Base	
R5005	Bracket; Arm Rest Support	
R5006L	Rest; Arm; LH	
R5006R	Rest; Arm; RH	
R5007	Seat; Pan; P2 incl 3 Cleats	
R5008	Joystick	
R5009	Grip; Hand; Joystick	
R5010	Bearing; 6304	
R5011	Pedal; Foot	
R5012	Pad; Rubber; Foot Pedal	
R5016	Rubber part; Catch; Cover; Transmission & Seat	
R5018L	Arm; Trailer; LH	
R5018R	Arm; Trailer; RH	
R5019	Drawbar; Pin Type	
R5020	Ball Coupling; 50mm; Optional	
R5020A	Drawbar; Optional; To suit R5020	
R5021	Catch; Drawbar; With Tab; For R5049 Spring	
R5022	Spring; Trailer Up	
R5023	Catch; Trailer Up	
R5025	Plug Kit; Plastic; 4 @ 35x35 + 2 @ 30x30	
R5026	Strut; Hydraulic; Obsolete; See Identification Chart & Supply R5210 Strut + correct kit	
R5027	Tyre & Wheel Complete	
R5028	Bearing; 6205; 25 ID 52 OD To Suit R5027 Wheel & R6042 Smoothing Tube	
R5029	Engine; Honda 4HP; GX120; LX2; LXU 2:1 reduction	
R5030	Coupling; Honda 4 HP Engine	
R5031	Coupling; Rubber	
R5032	Coupling; Eaton 7 Transmission; Honda 4.0HP	
R5033	Fan	
R5034	Transmission; Eaton 7	
R5035	Sprocket; Simplex; 11T & 1/8" Woodruff key	
R5036	Chain; Simplex; Eaton 7 Transmission; incl R5036A Joiner	
R5036A	Connecting Link; Joiner; Simplex; Chain	
R5037	Sprocket Assy; Simplex; 12Tooth; Inc. R5050 Bearing; R5188 Sprocket; R5180 & R5183 Circlips	
R5038	Arm; Chain Tensioner; One Only	
R5038 kit	Tensioner Kit; Chain; Replacement for early Chain Tensioner Arms with Steel or Nylon Bushes. Comprises 2 x R5038 Chain Tensioner Arms; 2 x R5037 Sprocket Assemblies; 2 x R5099 Bronze Bushes; 1 x R5094 Spring; 1 x R5101 Sizing Sleeve; 1 x R5041 Capped Wash	
R5039	Sprocket; 30 Tooth; Drive Roller; Eaton 7	
R5039A	Bush, Taper Lock; 30mm; 2012; for R5141 Sprocket 27 Tooth	

R5041	Washer; Capped; 1/2"	
R5043	Bracket; Transmission; Eaton 7	
R5044	Lever; Neutral; For Eaton 7 Transmission	
R5045	Yoke; Eaton 7 Transmission; To Suit R5048 Self-Centring Arm	
R5046	Rod Unit; Arm;Foot Pedal-Yoke;Transmission inc.1 x R5184 Rod; 2 x R5118 Rod Ends; 2 x 3/8" Nut	
R5047	Arm; Foot Pedal;for Eaton 7	
R5048	Arm; Self Centring	
R5049	Spring; Steering Return & Catch	
R5050	Bearing; 6000	
R5051	Strut; Transmission; Spec-081200Q0; To Suit R5048 Self-Centring Arm	
R5052	Bush; Nylon; Black; Use R5075	
R5061	Strap; Mud Flap	
R5066	Roller; Drive; suits RS48;RS48-11;RS48-11B	
R5067	Housing; F205; LF205 4 Hole; For R5070 B5 Bearing	
R5068	Housing; LFL5J; F205;2 Hole; For R5070 B5 Bearing	
R5070	Bearing; B5;25MM	
R5071	Mudflap 150mm X 160mm	
R5072	Arm; Steering; Attaches to Joystick	
R5073	Rod Unit; Steering Arm to Smoothing Head; Incl. 2 x R5118 Rod Ends; 1x R5185 Rod; 2 x 3/8" Nuts	
R5074	Bracket; Swivel; Smoothing Head; Incl. Plastic Plugs 40x40	
R5075	Bush; Nylon; Black; 27x16.9x32mm	
R5077	Housing; LFL6J; LF206 For R5078 B6 Bearings	
R5078	Bearing; B6;30MM	
R5079F	Head; Smoothing; Front; Frame Only	
R5079R	Head; Smoothing; Rear; Frame Only	
R5080	Spacer; For R5081 Carrier	
R5081	Carrier Mount; Bearing; Smoothing Head	
R5082	Tube; Smoothing; 570mm x 60mm OD	
R5083	Shaft; Smoothing Rollers;20mm	
R5084	Rod Unit; 560mm; Connecting Smoothing Heads; Incl. 1 R5194 Rod;2 x R5118 Rod Ends & R5187 Tube & 2 x 3/8"NF ZP Hex Nuts	
R5085-1	Shim;1mm Thick; Honda Engine	
R5085-2	Shim;2mm Thick; Honda Engine	
R5085-3	Shim;3mm Thick; Honda Engine	
R5087	Key; Woodruff; 8mm x 30mm	
R5088	Mat; Foot 300 x 180 x 3 Ribbed; Adhesive	
R5089	Key; Woodruff; 3/16"; For Joystick prior to "B" Series & in Eaton 11 Trans Coupling	
R5090	Key; Woodruff; 1/8" x 1/2"; For Eaton 7 Transmission,Yoke & R5035 Sprocket	
R5091	Engine; 5.5 HP; Honda; GX160 LX2;LX4;LXU	
R5092	Bush; Nylon; Red; Smoothing Head; Swivel	
R5093	Spring; Coil; Drawbar	
R5094	Spring; Arm;Chain Tensioner;90mm x 13mm x 1.5mm	
R5099	Bush; Bronze; For Chain Tensioner Arms	
R5100	Mount; Swivel; Smoothing Head - For Pivot Shaft;Supply R5104 Pivot Shaft	
R5102	Catch; Front Trailer; No Spring Tab; Use R5093 Spring	
R5103	Washer; 20 x 42 x 3mm; Fits Smoothing Roller Shafts R5106 & G4075	
R5104	Shaft; Pivot; To Suit R5092 Bush; Red; Nylon; In R5074 Bracket	
R5105	Coupling; Long; Engine; Honda 5.5 HP or Kohler 6.0 HP to Eaton 7 Transmission	
R5106	Shaft; Stepped; Smoothing Roller	
R5107	Ball Fitting; Strut; Trailer/Roller; 13mm Dia. M10 Thread	
R5108	Ball Fitting;Small Flange;Strut; Foot Pedal; 10mm Dia. M8 Thread	
R5109	Retainer; Clip; For R5115 Strut Cup End 13mm	
R5110	Ball Fitting; Strut; Trailer Roller; 13mm Dia. M8 Thread	
R5111	Retainer; Clip; For R5114 Strut Cup End 10mm	
R5112	Circlip; External; 25mm	
R5113	Washer; Flat; 24x44x2mm;Suits only R5028 Bearing	
R5114	Cup End; Standard;Strut; 10mm Dia. Ball; Foot Pedal	
R5115	Cup End; Strut; 13mm Dia. Ball; For Trailer/Roller	
R5116	Support; Self-Centring Arm	
R5117	Cover; Transmission; RS48;GR48;GR7000; 2 Catch Type	
R5118	Rod End; 3/8" UNF; For Threaded Rod (part Rod Units R5084;R5046;R5073)	
R5119	Light; 3" x 5"; 50 Watt	

R5120	Coil; Lighting; ZEI 711; For Honda 4HP & 5.5 HP	
R5121	Flywheel; Honda 5.5 HP; ZEI 811	
R5122	Bolt; Flange; 6 x 28; Coil; 883 000	
R5123	Switch; Light	
R5124	Harness; Wire; Incl. Tube	
R5125	Bracket; Lights; For Light Kit	
R5126	Bracket; Switch; For Light Kit	
R5127	Light Kit; Optional	
R5128	Bracket; Hour/Tach Meter	
R5129	Meter; Hour/Tach	
R5134	Arm; Self-Centring; Obsolete; To Suit R5161 Bearing 6200	
R5135	Yoke; Transmission; Used With R5134 Self-Centring Arm	
R5155	Bush; Taper Lock; 30mm; Use R5039A	R5039A
R5157F	Mesh, Body, Front; RS48 & RS48-11	
R5157R	Mesh; Body; Rear; RS48 & RS48-11	
R5158	Rubber Strip; Frame; Seat	
R5159	Rubber Strip; Rest; Trailer	
R5160	Sticker; Safety Pack; GR48	
R5161	Bearing; 6200	
R5164	Woodruff Key 4 x 6.5mm	
R5165	Scraper; Wire; 600mm; Set of 6	
R5166	Flywheel; Honda 4.0 HP; ZEO 811	
R5180	Circlip; External; 10mm	
R5182	Circlip External 1/2" 12.5mm	
R5183	Circlip Internal 1.0" 25.4mm	
R5184	Rod; 3/8" x 70mm; Connects Foot Pedal Arm To Transmission Yoke	
R5185	Rod; 3/8" x 270mm; Connects Steering Arm To Smoothing Head; RS48/RS48-11	
R5187	Tube; 12.7mm x 495mm; For R5084 Rod	
R5188	Sprocket Only; 12Tooth; Supply R5037 Sprocket Kit	R5037
R5190	Bracket; Trailer Strut Retro Body Mount; Red; RS48 Only	
R5191	Bracket; Trailer Strut Retro Arm Mount; Yellow; RS48 Only	
R5192	Kit; Trailer Arm Strut & Catch Replacement; RS48 Only; Incl. 1xR5190; 1xR5191 See Trailer Strut Identification Picture #2	
R5194	Rod; 3/8" x 570mm; Connects Right & Left Smoothing Heads; Part R5084	
R5195	Key; 32.5mm x 5mm x 5mm; Honda/Kohler Engines	
R5205	Kit; Smoothing Roller; RS48 & RS48-11; Incl. 1 x R5082 Tube; 2 x R5010 Bearings; 2 x R5103 Washers; 1 x R5106 Stepped Shaft; 1 x R5208 3/8" x 1" Hex Bolt; 1 x R51209 3/8" Spring Washer; 1 x R5211 3/8" CSK Screw	
R5208	Bolt; 3/8"x1" UNF Hex Head	
R5209	Washer; 3/8" Spring	
R5211	Screw; 3/8" x 1" UNF CSK	
R5212	Nut; 3/8" UNF	
R5213	Clip; Steel; Pinch Cleat; Seat	
R5215	Kit; Progressive Transmission & Foot Pedal Self-Centring; GR/RS Eaton 7; Incl. 1 x R5172 Yoke; 2 x R5173 Strut Kits	
R6040	Sticker; Sloping Greens	
R6041	Sticker; Danger, Cover Removal	